

HS3MAG1S

Wireless door and window sensor - White

Enjoy added peace of mind with the HS3MAG1S Wireless door and window sensor. Link the sensor with your existing Honeywell doorbell or home alarm kit, and get alerts whenever a door or window has been left open, or when someone enters or leaves your home.

**Both HS3MAG1S and HS3MAG1N are identical and interchangeable, the only difference are the other European languages on the packaging.,*



Pack Contents:

1 x Wireless Door and Window Sensor, 1 x CR2032 (3V) Battery, 1 x Quick Start Guide, 1 x Safety & Guarantee, 1 x Declaration of Conformity,

Key Features and Benefits:

Door Entry Alerts For added peace of mind, get alerts whenever someone opens a door or window. The wireless door and window sensor, enabled by Honeywell ActivLink™, connects with your Honeywell doorbell or home alarm system to trigger an alert sound.

Easy To Install All Honeywell push buttons and accessories are easy to install, with optional screw-free installation and an easy open battery compartment so you can be set up in minutes. All this is backed up by our 2 year product guarantee.

Specification:

Wireless Door and Window Sensor	
Colour	White
Wall mounted	Yes
Screwless mounting option (Sticky pads)	Yes
Frequency / Wireless Range*	868MHz / 200m
Power	Battery: 1 x CR2032 (3V) - (included)
Battery Life (Years)	2
Battery Features	Low Battery Indicator / Easy Open Battery Compartment
Test Mode	Yes
Tamper Protection	Yes
Operating Temperature/Storage Temperature	0°C to +40°C/-20°C to +60°C
Dimensions (mm) / Weight (g)	71 (h) x 40 (w) x 14 (d) / 28 (g)
Fixings	Screws / Sticky Pads

Pack	
EAN Code / Standard Pack EAN Code	5004100966049 / 5004100966209
Pack Dimensions (mm) / Weight (g)	137 (h) x 146 (w) x 30 (d) / 84 (g)

* Measured in open field conditions, walls, ceilings and metal structures will reduce the maximum range.