

## 3-phase cleaning tablets

### Tablets for cleaning and protecting JURA fully automatic coffee machines

#### Mode of action

Alkaline cleaning tablets especially developed for JURA fully automatic coffee machines for thorough removal of coffee fat and deposits. The formulation is tailored to use in JURA fully automatic coffee machines and ensures effective while gentle cleaning, thereby extending the life of your coffee machine. They can also be used for thermos flasks and other containers/devices where deposits must be removed. Please see that the tablets must be dissolved with water of at least 90 °C.

#### Properties

Tablet, cylindrical, convex bottom, hemispheric top  
Colour: white bottom/mid dark blue/blue top  
Neutral odour  
Height: < 15.2 mm  
Diameter: 16.1 mm ± 0.1 mm  
Weight: 3.4 g ± 0.1 g  
Soluble in water.  
Dissolving time (0.25 l/90 °C): < 10 min

#### Ingredients

(according to regulation (EC) No 648/2004)

SODIUM CARBONATE  
SODIUM CITRATE  
SODIUM GLUCEPTATE  
SODIUM CARBONATE PEROXIDE  
SODIUM SULFATE  
ADIPIC ACID  
SODIUM C14-16 OLEFIN SULFONATE  
MAGNESIUM STEARATE  
SULFURIC ACID, MONO-C12-14-ALKYL ESTERS, SODIUM SALTS  
COLORANT

For more information on the ingredients please click [here](#).

#### Instructions for use

1. Place a sufficiently large receptacle (ca. 0.5 litres) under the height-adjustable coffee spout.
2. Start the cleaning operation as described in the instructions for use of your machine.
3. Drop a cleaning tablet inside the filler funnel for pre-ground coffee.
4. The rest of the procedure is described in the instructions for use of your machine.

#### Packing units

Folding box of 2 tablets in a blister, folding box of 6 tablets in a blister, jar of 25 tablets, jar of 100 tablets  
Art. No. 59633, 68009, 58710, 24224, 24226, 24225, 24190, 24191

#### Toxicological and ecological information

The product is classified as irritant, i. e., short, frequently or prolonged contact with skin may cause inflammations. The product complies with the biodegradability criteria as laid down in Regulation (EC) No. 648/2004 on detergents.

#### Handling, storage and disposal considerations

Keep container tightly closed, protect against humidity, water and heat.  
Waste code product: 20 01 29

#### Hazards identification

Warning

H315: Causes skin irritation.

H319: Causes serious eye irritation.

P101: If medical advice is needed, have product container or label at hand.

P102: Keep out of reach of children.

P264: Wash hands thoroughly after handling.

P305+P351+P338: IF IN EYES: Rinse cautiously with water for several minutes. Remove contact lenses, if present and easy to do. Continue rinsing.

P332+P313: If skin irritation occurs: Get medical advice/attention.

P337+P313: If eye irritation persists: Get medical advice/attention.

#### First aid measures

In case of accident or if you feel unwell, seek medical advice immediately (show directions for use or safety data sheet if possible).

**General information:** No special measures required.

**After inhalation:** Supply fresh air.

**After skin contact:** Immediately rinse with water.

**After eye contact:** Rinse opened eye for several minutes under running water. Then consult a doctor.

**After swallowing:**

Rinse out mouth and then drink plenty of water.

Do not induce vomiting.

If symptoms persist, consult a doctor.

**JURA Elektroapparate AG**  
Kaffeeweltstrasse 10  
CH-4626 Niederbuchsiten  
Tel.: +41 (0) 62 389 82 33  
[www.jura.com](http://www.jura.com)

**JURA Elektrogeräte Vertriebs-GmbH**  
Postfach 99 01 44  
D-90268 Nürnberg  
Tel.: 0180 3 523 333  
[www.de.jura.com](http://www.de.jura.com)

**JURA Gastro Vertriebs-GmbH**  
An der Zugspitze 1  
D-82491 Grainau  
Tel.: +49 (0) 8821 966 73-0  
[www.juragastroworld.de](http://www.juragastroworld.de)