

# mill<sup>®</sup>

Assembly and instruction manual



## Series: PTC Fan Heater



EN

This product is only suitable for well insulated spaces or occasional use.

Please read the instructions carefully before use.  
Take good care of this manual for later use.





# Thanks for buying Mill

Our company was founded in Norway in 1992 by Cato Bryn, specializing in distribution of oil filled radiators and other types of heaters. From 1992 to 2009, we had gained significant knowledge and expertise of different type of heaters, thus enabling us to sell to many of the largest retailers in the Nordic countries.

In 2010, Cato's son, Phillip joined the company. Philip looked at the heating industry with fresh new eyes and wondered why there had been so little change with the appearance of portable heaters in the last 20 years, especially since interior design in general had changed dramatically over the years. Philip thought consumers should have more styles to choose from other than the typical old-fashioned, traditional heaters.

Since heaters are part of so many homes, Philip and Cato decided to use their extensive knowledge to re-invent the design of heaters. They wanted to create beautiful, modern and minimalistic heaters, using the most advanced technology, that would complement people's homes. They launched the brand "Mill" in 2012.

Mill offers revolutionary, innovative Norwegian designs. We are continuously innovating to complement our line of products to meet consumers' demand.

Prospering on our success in the Nordics we decided to promote Mill at some of the world's largest electronic fairs and home shows in 2015 and 2016 - the feedback from retailers and distributors all over the world were amazing. We are proud to say that consumers in over 25 countries can now **keep warm with style!**

## Follow us on social media:



[fb.com/millheat](https://fb.com/millheat)



[@millheat](https://@millheat)



[millheat.com](https://millheat.com)




[post@millheat.com](mailto:post@millheat.com)



# Content

- P. 2-3 | Important safety information
- P. 4 | Specifications
- P. 4 | Before first use
- P. 4 | First use
- P. 4 | Description of heater
- P. 4 | Parts
- P. 5 | Assembly
- P. 5 | Instructions
- P. 5 | Usage mechanical thermostat
- P. 7 | Maintenance
- P. 7 | Warranty
- P. 7 | Waste disposal

**Please read the instructions carefully before use.  
Take good care of this manual for later use.**



---

**STORE THIS INSTRUCTION  
MANUAL FOR FUTURE USE!  
NEVER TOUCH YOUR HEATER OR ITS  
CASING WITH WET HANDS!**

---



**IN ORDER TO AVOID OVERHEATING,  
DO NOT COVER THE HEATER.**



# Important safety information

**You must obey common safety guidelines when using electrical products, especially in the presence of children.**



**WARNING!** To avoid electric shock or damage due to the heat, always make sure the plug is pulled out before the heater is moved or cleaned.

## READ THE INSTRUCTIONS CAREFULLY

- The product is intended for home use only.
- Make sure the heater is connected to the house's regular mains as indicated on the heater.
- New heaters will produce a specific odor when used the first time. This will stop after a short time and is completely harmless.
- Check for any pieces of packing foam or cardboard that may have fallen into the heating elements of the heater. These pieces must be removed to avoid unpleasant odors.
- Prevent the heater from overheating – **do not cover.**
- Always turn off the heater and unplug it when not used for a long period of time.
- Pay special attention if the heater is used in rooms where children, the handicapped or elderly reside.
- The heater should not be set up directly beneath an electrical socket outlet.
- The cord must not be laid under any kind of carpet. Make sure the cord is laid in such a way that nobody can trip on it.
- The heater must not be used if either the cord or plug is damaged. The heater must not be used if it has been dropped on the floor or is damaged in any other way causing it to malfunction.
- The cord must be repaired by the manufacturer or by an expert if it has been damaged, to avoid dangerous situations.
- Avoid using extension cords, which may overheat and could possibly start a fire.
- Never cover the air vents on the heater. Avoid potential fire hazards by making sure the air intakes are not blocked or covered. The heater should be used in rooms with normal flat floors.
- The heater should not be installed in close proximity to flammable materials of any kind because there can always be a risk of fire.



- The heater must never be used in rooms where gasoline, paint or other flammable liquids are stored, such as in a garage.
- Never touch an electric heater with wet hands. The heater should be installed so a person showering or taking a bath cannot come into direct contact with it.
- Some parts of this product can become very hot and cause burns. Particular attention has to be given where children and vulnerable people are present.
- The heater must be switched off, the plug removed and the heater must cool down before it is moved.
- Avoid overloading the mains (the circuit) where the heater is connected. The heater may overload the electrical circuit if other electrical devices are plugged into the same socket outlet.
- Do not use this heater in small rooms when they are occupied by persons not capable to leaving the room on their own, unless constant supervision is provided.
- The product cannot be used by children under 8 years of age and persons with reduced physical or mental abilities or lack of experience and knowledge unless they have been given supervision or instruction in the safe use of the product and understand the hazards involved.
- Children should not play with the product. Cleaning and maintenance should not be done by unsupervised children.
- Children under the age of 3 should be kept away from the product, unless they are under constant supervision.
- Children aged 3 to 8 years are only permitted to turn the product ON/OFF, assuming the heater is mounted according to the assembly instructions and the children have received instruction or supervision in the safe use of the product and understand the hazards involved.
- Do not use this heater in the immediate surroundings of a bath, a shower or a swimming pool.

**ATTENTION! This heater is only meant to be used as a supplementary heating source, and must not be used without supervision**



## Specifications

Model	Thermostat	Color	Aluminium foot	Amperage	Power (W)
<b>CUS1800MECWA</b>	Mechanical	White	Yes	~220-240V/50Hz	1800
<b>CUS1800MECBA</b>	Mechanical	Black	Yes	~220-240V/50Hz	1800
<b>CUS1800MECGA</b>	Mechanical	Silver	Yes	~220-240V/50Hz	1800
<b>CUS1800MECW</b>	Mechanical	White	No	~220-240V/50Hz	1800
<b>CUS1800MECB</b>	Mechanical	Black	No	~220-240V/50Hz	1800
<b>CUS1800MECG</b>	Mechanical	Silver	No	~220-240V/50Hz	1800

## Before first use

After unpacking the heater, check to make sure the product was not damaged during transport. Contact the retailer or importer if you discover any visible damages to the product.

Keep the outer packaging to transport the heater in the future. If you want to dispose of the packaging, make sure it is done properly. Keep plastic bags away from children.

## First use

After turning on the heater for the first time or after an extended period without use, the heater can produce a burnt odor for a short time. This is normal.

Please read all the instructions carefully before use. Save the instruction manual for future use.

## Description of heater

See figure 1 on separate illustration sheet

### **A** With aluminium foot

1. Heat emission
2. Thermostat
3. Output selector
4. Legs (aluminium)

### **B** Without aluminium foot

1. Heat emission
2. Thermostat
3. Output selector

## Parts for models with aluminium foot

See figure 2 on separate illustration sheet

- 8 screws (4 pre-mounted)
- 2 foot brackets
- 2 rails for the feet

# Assembly

See figure 3 on separate illustration sheet


1. Remove the pre-mounted screws on both legs before you insert them into the brackets, so that you get a stable foot.
2. Attach the legs to the brackets by tightening 2 screws into each bracket. Do not tighten completely in order to fit the foot into the square tracks of the heater.
3. Place the heater gently on its head and use the supplied screws to mount the feet.
4. Place the foot in the square tracks and fasten each foot bracket with two screws. Wait to tighten the screws until all four screws have been fastened. You can now tighten the screws attaching the legs and brackets.

**5. NEVER USE THE HEATER BEFORE THE LEGS HAVE BEEN TIGHTLY SCREWED.**

## Instructions

### Control Panel

See figure 4 on separate illustration sheet

1. Thermostat: Adjust the desired heat setting
2. Output selector:
  - O: OFF
  -  Fan (only fan, no heating)
  - I: 1200W
  - II: 1800W


---

**WARNING!** BE SURE THE FOOT IS FITTED CORRECTLY AND ACCORDING TO THE INSTRUCTIONS BEFORE USING THE HEATER!

---

**ATTENTION!** This heater is only meant to be used as a supplementary heating source, and must not be used without supervision

## Usage

1. Set the output selector to the OFF position (O) and the thermostat to minimum. Plug the heater into a grounded outlet.
2. Set the output selector to position  for fan only (no heating).
3. Set the output selector to position I or II. Turn the thermostat up to the maximum position. When the desired room temperature has been reached, turn the thermostat slowly down until you hear a click. The thermostat can now remain in this position until a different room temperature is desired. As soon as the room temperature falls below this level, the heater will automatically switch on again. When the room has again reached the desired temperature, the heater will switch off again.
4. If you wish to change the room temperature, repeat the instructions in step 3.
5. The heater has an overheat protection that turns the device off if any parts become extremely hot.
6. To switch the heater off, turn the output selector to the O position. If the heater will be left unused for a longer period of time, pull the plug.





# Seasonal energy efficiency

## Information requirement for the electric local space heaters

Model identifier(s): CUS1800MECWA, CUS1800MECW, CUS1800MECBA, CUS1800MECB, CUS1800MECGA, CUS1800MECC

Item	Symbol	Value	Unit	Item	Unit
<b>Head Output</b>				<b>Type of heat input, for electric storage local space heaters only (select one)</b>	
Nominal heat output	P <sub>nom</sub>	1,8	kW	manual heat charge control, with integrated thermostat	No
Minimum heat output (indicative)	P <sub>min</sub>	0,0	kW	manual heat charge control with room and/or outdoor temperature feedback	No
Maximum continuous heat output	P <sub>max,c</sub>	1,8	kW	electronic heat charge control with room and/or outdoor temperature feedback	No
<b>Auxiliary electricity consumption</b>				fan assisted heat output	No
At nominal heat output	el <sub>max</sub>	1,800	kW	<b>Type of heat output/room temperature control (select one)</b>	
At minimum heat output	el <sub>min</sub>	0,025	kW	single stage heat output and no room temperature control	No
In standby mode	el <sub>SB</sub>	0,000	kW	Two or more manual stages, no room temperature control	No
				with mechanic thermostat room temperature control	Yes
Seasonal space heating energy efficiency	η <sub>s</sub>	36 %		with electronic room temperature control	No
				electronic room temperature control plus day timer	No
				electronic room temperature control plus week timer	No
				<b>Other control options (multiple selections possible)</b>	
				room temperature control, with presence detection	No
				room temperature control, with open window detection	No
				with distance control option	No
				with adaptive start control	No
				with working time limitation	No
				with black bulb sensor	No
Contact details	Mill International AS Grini Næringspark 10, 1361 Østerås, Norway				





## Maintenance

1. For cleaning, always unplug the heater and leave it to cool.
2. Wipe the heater regularly with a damp cloth and dry the surface before turning on the heater again.
3. The heater must be cleaned at least once a month during the heating season.

**CAUTION! The heater should never be immersed in water.**

**Avoid using detergents to clean the heater.**


**Never let any water get inside the heater; this can be hazardous.**

4. Dust etc. should be removed with a soft cloth.
5. The heater can be stored in a dry and clean place.
6. If the heater stops working, do not attempt to repair it yourself because it can cause a fire hazard and/or electric shock.

## Warranty

The warranty is valid for 2 years. The heater will be repaired or replaced during this time should any malfunction occur. The warranty applies if the heater is used according to these instructions and the customer can present a purchase receipt. If the heater malfunctions in any way, please contact the store where it was purchased or the importer.

## Waste disposal

The symbol  indicates that this product is not to be disposed of together with household waste. This product must be delivered to a recycling service or container for electrical appliances and electronic equipment. This is done to avoid health risks and prevent harm to the environment. Local businesses (or the environmental station in your neighborhood) are required by law to accept and recycle such products, as a means of environmentally sound disposal.







mill®

**Mill International B.V. - [www.millheat.com](http://www.millheat.com)**

Designed by Mill in Norway ©All Rights Reserved.

Made and assembled in China.

Exclusively distributed and imported by BML L24 9WD UK ©2017

**[www.millheat.co.uk](http://www.millheat.co.uk)**

**[info@millheat.co.uk](mailto:info@millheat.co.uk)**